

Miller Wire Works, Inc. BUCKET SIDE WALL PROTECTION

Don't pretend to protect with wear pieces or hard surfacing here and there.

Cover those side walls! Keep the OEM bucket like new!

Kenco Chromium-Carbide Overlay Plates



Solid 5/8" thick custom-shaped plates with overlay placed to provide strategic protection. Slotted weld holes for easy installation.

Kenco Wear Patch 60 Rockwell "C" (600 Brinell)



Kenco Tungsten-Carbide Corner Guards



OEM Corners Guards damage bucket before wearing out



Kenco Tungsten-Carbide Wear Strip



Kenco Tungsten-Carbide Half Arrow Bolt-on



Fax: 205-599-7172

Phone: 800-783-0341 Email: screen@millerwireworks.com